

Warning gate may
move suddenly do
not stand in gate
path, do not touch
110 volt terminal

do not
touch
110 volt
terminal

"ANT"
l.e.d.

Press learn button you will
hear a tone and "ANT" l.e.d.
will illuminate, press desired
button on your remote hold
down ANT l.e.d. will begin to
flash let transmitter button go
when ANT l.e.d. stops flashing
your transmitter is
programmed

